EPILADY®

Legend 4th Generation

Rechargeable Hair Remover
Model No.: 810-33A

USER MANUAL

www.epilady.com

With your new LEGEND, you can remove unwanted leg and arm hair quickly and effectively. The LEGEND is suitable for every hair type.
LEGEND'S innovative and patented epilating head removes even the shortest hairs (0.5 mm), and can be operated corded or cordless (rechargeable batteries built in). The Two-speeds allow you to choose the best option for your own personal needs.

BEFORE USE, PLEASE READ ALL THE INSTRUCTIONS CARFULLY!
Wash legs with warm water and soap and dry thoroughly. Do not apply any body lotion or other substances such as talc. To expose under-skin hair growth, rub a coarse sponge or a loofah over your legs, against the direction of hair growth.

BEFORE 1ST USE
Check that the voltage indicated on the transformer corresponds to your home voltage and use only the transformer provided.
Place the on/off switch in the "0" position. Plug the electrical cord into the unit. Connect the transformer to an electrical outlet; the red LED (G) will turn on indicating that the batteries are being charged. Charge the batteries for at least 12 hours. This needs to be done even if you are planning to use the LEGEND only corded.

The LED will remain red any time the unit is plugged in. It will not change color when fully charged.

For Cordless Operation:
Just follow the epilation instructions below.
Charging The Batteries After Use:
Regular charging time should be 8 hours. Note that although charging for more than 8 hours will not damage the unit, it may shorten the life span of the batteries.

For Corded Operation:
Connect the transformer first to the LEGEND and then to an electric outlet and follow the epilation instructions below.

EPILATION
Stretch the skin taut. Place the LEGEND at a slight angle to your leg, with the switch facing you (fig.1). Turn the LEGEND on to the desired speed (fig.2). Move the LEGEND in small circular movements, **lightly skimming the skin's surface, and without applying pressure** (fig.3). Be careful when using the LEGEND on sensitive areas.

TO REMOVE HAIRS FROM THE INNER KNEE
Always keep your leg straight and skin stretched to prevent it from being pinched by the rotating head (fig.4).

AFTER USE
A slight irritation and/or redness may appear on the skin, especially after the first use. These irritations should disappear after a short time. If it persists for 48 hours or more, please consult your doctor. Any light moisturizing cream will refresh your skin and should be applied no less than 30 minutes after epilation.

CLEANING AND MAINTENANCE
Thoroughly clean the epilating head after every epilation: Remove the epilating head housing (B) by pressing the epilating head housing release buttons (D) on both sides while pulling it out (fig.5). Remove all the accumulated hairs between the metal and plastic parts by using your cleaning brush, or by blowing on it. Relocate the epilating head housing (B) until it clicks in place. Return the transparent protective cap (A) after every use.

DO NOT REMOVE THE SILVER BAR ON THE EPILATING HEAD

IMPORTANT!
Use only the original transformer supplied with the LEGEND.
Do not use the LEGEND on open cuts, bruises, sunburns or blisters.
Do not use the LEGEND in the bath or shower.
Do not use the LEGEND if a fault has been discovered, or if the transformer or the electric cord are damaged.

Contact your Service Center for any repairs.
If your skin is sensitive, or if you suffer from varicose veins, hemophilia or a skin disease, consult your physician before use.
The working LEGEND should never come in contact with the hair on your head or eyelashes.
Keep out of reach of children.
Unplug transformer from the electric outlet after use / charging.

ATTENTION:
Rechargeable batteries must be recycled or disposed of properly.
Contact your Service Center to replace your spent rechargeable batteries when needed, and NEVER throw it into your trash!

APPLIANCE PARTS
A. Transparent Protective Cap
B. Epilating Head Housing
C. Epilating Head
D. Epilating Head Housing Release Button
E. ON/OFF Switch
F. Body
G. LED Charging Indicator
H. Transformer
I. Cleaning Brush







GUARANTEE

CAUTION!
This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance, by a person responsible for their safety.

WEEE / ENVIRONMENTAL PROTECTION

Disposal of Electrical and Electronic Equipment
Do not dispose of this product with household waste.
For the proper treatment, recovery and recycling please take this product to the appropriate waste collection point. If you are unsure where this may be, please contact your local authority. Improper disposal may be harmful to the environment.

1 YEAR GUARANTEE
NOTE: THESE STATEMENTS DO NOT AFFECT YOUR STATUTORY RIGHTS AS A CONSUMER.
This product has been manufactured under the strictest of quality control procedures, and using the highest quality of materials, to ensure excellent performance and reliability.

Name

Address

Purchase date

Purchased at (please include copy of receipt)

www.epilady.com